



NOTES:

1. Restrained Joint (Megalug) or equivalent required on all fittings.
2. Thrust Blocks to be used at 22.5° or greater bends.
3. Thrust Blocks to be poured or placed against firm undisturbed soil. Use Class SI Concrete. Pre-cast blocks must be 3000 psi min.
4. Sacrificial zinc anode nuts are to be installed on all bolts.

THRUST BLOCK INSTALLATION

Issued by: DLZ	10/11/00
By	Revised Date
SD	1/4/06
MJ	6/24/14
JB	12/15/22

VILLAGE OF GURNEE
ENGINEERING DIVISION

Approved by:
SD 1/4/06
SD 6/24/14